



\* NOTE: FOR DC-OPERATED CONTACTORS, THE DC AUXILIARY BLOCK AND ECONOMISING RESISTOR ADD 1.00" TO THE WIDTH OF THE EH CONTACTORS.

### EH 700 STARTER / T900

ABB Control Inc.  
5-20-98  
REV. B