



* NOTE: FOR DC-OPERATED CONTACTORS, THE DC AUXILIARY BLOCK AND ECONOMISING RESISTOR ADD 1.00" TO THE WIDTH OF THE EH CONTACTORS.

EH 800 STARTER / T900

ABB Control Inc.
 5-20-98
 REV. B